

---

**110 BLOCK ADAPTERS MODELS:** ITC-3002B, ITC-3002B-3, ITC-3012, ITC-3013, ITC-3014, ITC-3015 and ITC-3016.

Independent Technologies 110 Adapters are intended for use when connecting to the **AT&T** 110 cross connect system.

**INSTALLATION:** Insure the adapter is in the upright position and properly aligned with the appropriate grouping of three, four or 25 pair contacts on the 110 hardware, starting with the tip (left) conductor. Press the adapter onto the contacts in a rocking motion, (from left to right) until it is firmly seated and locked in place.

To remove three and four pair 110 adapters, grasp firmly and pull straight off. Twenty-five pair 110 adapters should be removed in a rocking motion similar to the installation procedure.

---

**66 BLOCK ADAPTER MODEL:** ITC-3002C

Independent Technologies' 66 Adapter is intended for connection to the 66B and the 66M type terminal blocks.

**INSTALLATION:** Insure the adapter is in the upright position. Align the adapter with any combination of vertical lugs. Push the adapter straight on, until it is firmly seated.

To remove the adapter, grasp firmly and pull straight off.

---

**BIX BLOCK ADAPTERS MODELS:** ITC-3008 and ITC-3009

Independent Technologies BIX Adapters are intended for use in connecting to the Northern Telecom cross connect system.

**INSTALLATION:** Insure the adapter is in the upright position and properly aligned with the appropriate grouping of three or four pair BIX hardware, starting with the tip (left) conductor. Press the adapter onto the contacts in a rocking motion, (from left to right) until it is firmly seated and locked in place.

To remove the adapter, grasp firmly and pull straight off.

---

**Do not attempt to install any of these adapters upside down or over cross-connects**

**Do not attempt to install any of these adapters on anything other than the appropriate 110 block, 66 block or BIX type hardware.**

READ AND SAVE THESE INSTRUCTIONS

**Caution:**

For indoor use only

Never install telephone wiring during a lightning storm

Use caution when installing or modifying telephone lines

Never install telephone jacks in a wet location

Never touch bare telephone wires or terminals unless the telephone line has been disconnected at the network interface

FOR ORDERING INFORMATION CONTACT:

**INDEPENDENT TECHNOLOGIES**

11422 Miracle Hills Drive Suite 500

Omaha, NE 68154 (402)496-4700

©Copyright 1991 Independent Technologies, Inc.

UL<sup>®</sup>